



#### SPECIFICATION

"Sorrento Collection", manufactured in Chrome plated brass finish.

#### INSTALLATION

All Premium Product series are mounted on the surface of a wall. Simple and easy installation of all products.

Stainless Steel screws supplied. \*note:- It is the responsibility of the installer to ensure correct fixings for the application to be used. The screws supplied may not be suitable for particular applications.

1. Use **Bracket** as template to locate appropriate drilling centres with pencil.
2. Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert **Plastic Anchors**.
3. Attach **Bracket** to wall with **Wall Screws**.
4. Locate the **Main Part** on the **Bracket** and secure with **Set Screw**.

#### WARRANTY

One year

#### OPERATION

Supply of all consumable items is restocked/refilled on a cycle determined by maintenance needs.

**Single Robe Hook** shall be Model No. JDM-8253 as supplied by ASI JD MacDonald.

