



SPECIFICATION

Theft Resistant Spindle shall be fabricated of hi-impact resistant ABS plastic. Unit shall accommodate a standard spring-tension plastic roller (ASI JD Macdonald Model No. 10-R-003, supplied separately) to provide increased vandal resistance. Unit shall fit into all standard holders that receive 10-R-003 and shall hold standard roll tissue with 35mm ID core. 10-R-009 can be used in conjunction with items 10-7305, 10-7305-2, 10-7402, 10-74022 and 10-0697-GAL.

INSTALLATION

Insert smaller diameter end (inside telescope) spring loaded roller from dispenser inside screw cap. Screw cap onto threaded body to contain larger (outside telescope) diameter end until 10-R-009 length is 1.6mm less than spacing between dispenser posts (supplied separately). Load 10-R-009 with toilet paper and insert into dispenser posts.

WARRANTY

One year.

OPERATION

Paper core must be ripped off to remove 10-R-009 after roll is exhausted. Grasp inside roller through opposing windows and retract pivot end from holder socket.

Theft Resistant Spindle shall be Model No. 10-R-009 as supplied by ASI JD MacDonald.

